

**HD REPLACEMENT LEVERS INSTALLATION**

**Tools & Supplies Needed:**

- Snap Ring remover
- Phillips Screwdriver
- Flat Blade Screwdriver
- ½" Open Box Wrench

**Install Brakelever**

1. Remove snap ring and pivot pin from stock lever.
2. Remove stock lever from housing.
3. You can use the nylon bushing as installed in the Highway Hawk lever.
4. Place lever back into control housing and replace pivot pin and snap ring.

**Install Clutch Lever**

1. Loosen the clutch tension nuts located at the lower end of the clutch cable, so that the stock clutch lever can be removed.
2. Remove snap ring and pivot pin holding the clutch lever in place.
3. Pull clutch lever from housing.
4. To remove cable from stock lever, push the plastic pin out and replace into Highway Hawk lever.
5. Place the Highway Hawk clutch lever, with cable attached, back into the hand control and secure with pivot pin and snap ring.
6. Tighten the tension on the clutch cable and adjust as needed.

**\*NOTE: Always test Brake and Clutch operation before riding.**

**\*NOTE:** Motorcycles modified with some aftermarket parts, accessories and performance parts may be restricted from use on public roads and/or limited to closed courses. Please see U.S. EPA and your state regulations. Customers must exercise good judgment in the use, control, alteration, part selection and installation and maintenance of motorcycles. It is the sole and exclusive responsibility of the user to determine the suitability of the product for use and the user shall assume all legal, personal injury risk, and liability and all other obligations, duties and risks associated therewith.

**Chrome Warranty**

Chrome plating is delicate and not designed for long lasting use in billet aluminum or steel parts. Chrome platers will only warrant their chrome plating until installed on a motorcycle or other vehicle.

**ONE YEAR WARRANTY AFTER INSTALLATION OR USE!**

You should expect tiny blemishes or scratches on chrome. Chrome platers can only strive for perfection. Once a week, or after every ride, use a good chrome cleaner to remove road dirt and other contaminants to help protect your chrome.



**This accessory should be mounted by a professional mechanic only.**

**MotoLux International B.V. / Highway Hawk can not be held responsible for improper installation.**

**© Moto-Lux Specialties B.V.**

**Barneveld - The Netherlands**